# Harmony® LED

| Orange | Battery status |
|---|---|
| ❙❙❙ or ❙❙❙❙ | Good battery |
| **(Steady Orange)** | Low battery |
| ❙❙ ❙❙ ❙❙ | Change battery |
| **Green** | **Microphone status** |
| Flickers green in response to loud sounds | Good |
| **(Steady green)** | Indicates empty program slot suitable for performing microphone test |
| **Red** | **Lock Status** |
| ❙ ❙ ❙ ❙ ❙ ❙ ❙ ❙ (1 sec interval) | No lock |
| ❙❙❙❙❙❙❙❙❙❙❙❙ | Wrong implant linked |
| **(Steady Red)** | Processor error condition (remove and reinsert battery to reset) |